



### **SPECIAL APPLICATIONS**

**Includes Conductive Floors as well as Shower and Locker Room Walls and Floors.**

#### **Conductive Floors**

After installation, thoroughly clean floor with solution of QT® disinfectant/detergent. Clean thereafter as required. Avoid any further treatment which might leave grease, wax, dust, soap film or other insulating substances on the floor. For proper maintenance of conductive surfaces, only use products which are classified by Underwriters Laboratories, Inc. as to electrical conductivity when used on conductive floors and spontaneous heating.

#### **Shower and Locker Room Walls and Floor Tile**

##### **NEW**

Maintain daily using QT® disinfectant/deodorant. Once per week, clean shower stalls with SHOWER FOAM®.

##### **OLD**

Renovate old shower room and locker room wall and floor tile with EXTRA STRENGTH C.S.P. CLEANER. Maintain daily as described above under "NEW".