



WOOD FLOORS
True Parquet, Tongue and Groove, or Strip Flooring (Raw Wood)

Conventional Solvent Based Seal

Water Based Seal

NEW FLOORS

1. Preparation

After proper sanding, sweep floor with push broom, vacuum and tack with KLEEN-UP SOLVENT. Allow floor to dry one(1) hour.

2. Sealing

Medium to High Gloss System

Apply COURT GUARD water based seal following label directions. Allow 2-4 hours drying and abrade with maroon pads, tack floor with TACK-IT and allow floor to dry. Apply 1 – 2 coats of TIP-OFF (water base urethane / acrylic) following label directions.

Satin / Low Gloss System

Apply COURT GUARD water based seal following label directions. Allow 2-4 hours drying and abrade with maroon pads, tack floor with TACK-IT and allow floor to dry. Apply 1 – 2 coats of UPHOLD, (water based satin finish) following label directions.

OLD FLOORS (PREVIOUSLY SEALED WITH A WOOD SEAL)

1. Sealing

Medium to High gloss

Seal as described above for TIP-OFF finish application, 1-2 coats of TIP-OFF (water based urethane / acrylic) following label directions.

Satin / Low gloss

Seal as described above for UPHOLD finish application, 1-2 coats of UPHOLD (water based satin finish) following label directions.